



41595 - Vehicle Wiring Installation Instructions

Chevrolet Impala 2006-2009

1. Open trunk. Temporarily remove the rear threshold plate. Partially remove the felt trunk liner behind the taillights.
2. On the driver and passenger sides of the vehicle, locate the vehicle's taillight wiring harness. The taillight wiring harness will have a connection point, on both sides, matching the ends of the T-Connector. Separate this connector, being careful not to break the locking tabs. All connector surfaces should be clean and free of dirt.
3. On the driver side, insert the Hopkins® T-Connector end with the yellow wire between the vehicle wiring connectors and lock into place. Be careful not to damage the locking tabs and be sure that connectors are fully inserted with locking tabs in place.
4. Route the T-Connector end with the green wire to the passenger's side behind the felt trunk liner and along the threshold. Repeat Step 3 using T-Connector containing the green wire.
5. Locate a suitable grounding point near the connector. Drill a 3/32" hole and secure the white wire with the ring terminal with self tapping screw (provided). Verify what is behind any surface prior to drilling to avoid damage to the vehicle. Do not drill into any exposed surfaces.
6. Route the end with 4-way flat down out through the taillight pocket between the bumper and body and towards the center of the bumper. Secure wires with ny-ties (provided).
7. Reinstall the felt trunk liner, threshold, and other items removed during installation, being careful not to pinch or cut the wires.
8. Attach the 4-way flat dust cover (provided) to the 4-way flat connector.
9. Apply a small amount of grease (provided) to the 4-way flat terminals to prevent corrosion.
10. Plug completed wire harness into the trailer 4-way flat connector.
11. Test all functions with the engine running to ensure proper operation.

TIPS:

Grease applied to the wiring terminals on a regular basis will help prevent corrosion.

Always unplug boat trailer connector before backing trailer into the water.

Need Help? (English Only)
1-800-835-0129
techsupport@hopkinsmfg.com
www.hopkinstowingsolutions.com