

#47905

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Attach the color wires to the SAME FUNCTIONS on the tow vehicle.
3. Check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail / parking lights and operate directional signals to check right / left turn.

WIRING IDENTIFICATION

WhiteGround

YellowLeft turn

GreenRight turn

Brown.....Park / tail

Blue.....Reverse

-
1. Escoja una localización de instalación en la parte trasera del vehículo o dentro del baúl donde el convertidor estará protegido. Evite el sistema de escape, amortiguador y tren de transmisión.
 2. Conecte los cables de color a los cables de MISMA FUNCIÓN en el vehículo de remolque.
 3. Revise el sistema de luces para la operación correcta. Ponga el freno para revisar las luces de frenos, encienda las luces para revisar las luces traseras / estacionamiento y opere las señales de dirección para revisar direccional derecha / direccional izquierda.

IDENTIFICACIÓN DE CABLEADOS

BlancoTierra

AmarilloDireccional
izquierda

VerdeDireccional
derecha

CaféLuces de
traseras

AzulReversa