

# #48015

1. Choose an installation location at the rear of the vehicle or inside trunk. Avoid exhaust system, shock absorbers and drive train.
2. Attach wires to the SAME FUNCTIONS on the tow vehicle
3. Plug into trailer and check the lighting system for proper operation. Step on the brake to check brake lights, turn on headlamps to check tail / parking lights and operate directional signals to check right / left turn.

## WIRING IDENTIFICATION

WHITE..... GROUND  
RED..... BRAKE  
GREEN..... RIGHT TURN  
YELLOW.... LEFT TURN  
BROWN..... PARK / TAIL

---

1. Escoja un lugar de instalación en la parte trasera del vehículo o dentro del la cajuela donde el convertidor estará protegido. Evite el sistema de escape, amortiguador y tren de transmisión.
2. Conecte los cables a los cables de MISMA FUNCIÓN en el vehículo de remolque.
3. Conecte en al remolque y revise el sistema de luces para la operación correcta. Ponga el freno para revisar las luces de frenos, encienda las luces para revisar las luces traseras/ estacionamiento y opere las señales de dirección para revisar direccional derecha/direccional izquierda.

## IDENTIFICACIÓN DE CABLEADOS

BLANCO — TIERRA  
ROJO — FRENO  
VERDE — DIRECCIONAL  
DERECHA  
AMARILLO — DIRECCIONAL  
IZQUIERDA  
CAFÉ — ESTACIONAMIENTO  
TRASERAS